





Physics and chemistry of nanostructures

Progress Navolchi project March 12th, 2012

Prof. Zeger Hens Ghent University Belgium



Physics and Chemistry of Nanostructures Group







- Materials
 - PbX/CdX heterostructures
- Processing
- Properties
 - Absorption enhancement in QD monolayers
 - Intraband absorption with PbX QDs
 - Pump-probe measurements -> amplification
- Devices
 - Absorbance of functionalized waveguides
 - Planning of future work





PbS/CdS multiplie dot-in-rods



- Successive cation exchange steps transform original CdS rod into a PbS/CdS multiple dot-in-rod
- Passivation by CdS enhances PLQY to 45-55%

Justo et al., J. Am. Chem. Soc. 2012, 134, 5484-5487





PbS/CdS dot-in-rods

PbS/CdS dot-in-rods









PbSe/CdSe rods

Similar synthesis as PbS/CdS dot-in-rods





Physics and Chemistry of Nanostructures Group Represented by Yolanda Justo

Intraband absorption





- Potential for switching
- Setback for gain (raises threshold)



Physics and Chemistry of Nanostructures Group Represented by

De Geyter et al., accepted by ACS Nano



Absorption enhancement

Measurement of absorption cross section of QDs in close packed monolayer





Geiregat et al., under review at ACS Nano





Physics and Chemistry of Nanostructures Group

Absorption enhancement

Measurement of absorption cross section of QDs in close packed monolayer



Geiregat et al., under review at ACS Nano





Physics and Chemistry of Nanostructures Group





Represented by

20



White light (up to 1600 nm) is created in sapphire crystal through 1028 nm pumping (fundamental of laser oscillator Nd:KGW).





PbS rods 4 x 12.8 nm

Analysis around Band Gap



Pump dependent spectra



Represented by

Bleach maximum redshifts due to increased multi-exciton shifts

At gain transition (ca. 1400 nm) you evolve from an absorbing transition at low fluence to a full bleach at high fluence.

How ?

Competition between PA and gain buildup with different dependence on carrier density?



PbS rods 4 x 12.8 nm

Analysis in the visible



- Pronounced PA absorbance also for supra bandgap light
- Measurements also done on PbS dots analysis ongoing









GENT

Non-planarized



 λ (nm)

Effective medium refractive refractive index (MG): n=1.876 K=0.034



UNIVERSITEIT GENT



Physics and Chemistry of Nanostructures Group

t

Planarized as functions of layer thickness



SiO₂	Si	SiO2
	SiO ₂	

UNIVERSITEIT GENT



Physics and Chemistry of Nanostructures Group

Future work

- Materials syntesis
 - HR-TEM analysis of PbSe/CdSe QDs
- Continuation of Transient Absorption
 spectroscopy
 - Benchmarking relative to PbS and PbS/CdS QDs
 - Analysis of PbS/CdS and PbSe/CdSe dot(s)-in-rod
- Sample exchange with Valencia
 - New batches have been sent



